# Flexnet Quick Connector



## Netafim

Netafim supplies a Quick Connector especially for Flexnet HP-PP hoses (formerly Flatnet). With this connector, connecting an item such as a sprinkler or dripline to Flexnet HD hoses only requires a simple movement. The range consists of 3 types of guick connectors, and one type of blanking plug. The connector blanking plug can be left in the Flexnet when the hose is rolled up.

#### **APPLICATION**

Removable seasonal coupling (for sprinklers and driplines on Flexnet or similar  $\frac{1}{2}$  connection)

#### **CHARACTERISTICS**

**Pressure** losses

Quick and easy way to make Flexnet branches

#### **INSTALLATION & MAINTENANCE**

- The blanking plug should be inserted with a large flat-head screwdriver.
- The female connector plug should be inserted with an 8-mm Allen key (6-sided) or a 26-mm open-ended spanner.

#### **TECHNICAL DATA**

FXN Blanking plug (1) Screw thread Material

### Connector plug female (2)

Screw thread Material

Seal Maximum pressure

# Connector PE male (3)

Connection

Material

Maximum pressure Nominal size Max. recommended capacity : 500 l/h

#### Connector protective cap (4)

Material

(1)

(3)

- : ½" BSP : PP (body) : EPDM or NBR (O-ring)
- : ½" BSP : PP or POM - polyacetal (body) : conical : 4 bar
- : PE 12 mm (9-10 mm internal) : PP or POM - polyacetal (body) : EPDM or NBR (O-ring) : 4 bar : 5.5 mm

Connection

: PE 12 mm : PP or POM - polyacetal (body)

(2)

(4)









