Punching equipment



Manual punch / Dripper inserter
A 2,5 mm punch is required for almost all drippers

02339-450602	Manual punch 2,5 mm (1)
45000-000042	Inserter tool Kameleon/Woodpecker for pre-punched dripline (2)

- Application: Capillary, CapiNet, single connection, Pulsator, Kameleon(-High), Bubbler, Woodpecker, CNL (Mataf)

Manual punch for microtube
A 3,0mm punch is used for dripper microtube (except Capillair en CapiNet)

02339-450599	Manual punch 3 mm (1)
45000-001600	Punch wrench (blue-white) for 16-20 mm PE-tube (3)
45000-001620	Punch wrench (green-black) for 25-32 mm PE-tube (4)
45000-001000	Manual punch aluminium 3 mm (5)
02339-450604	Manual punch Cobra - expander (6)

- Application: Cobra tube, thread screw tube and Woodpecker tube

Manual punch for DAN-sprinklers (4 / 4-7 mm)
A 3,2 mm manual punch is used for most DAN products. Since 2025, the DAN foggers in combination with the PE100 fogger pipe are an exception: the 3.0 mm hand punch must be used for this purpose.

71850-105890	DAN manual punch 3,2 mm barb (7)
02339-450599	Manual punch 3 mm (1)

- Application: NDJ barb, NDJ agriconnector, NDJ Turbojet en NDJ Hurricane
- **Note:** A suitable punch is NOT available for the NDJ barb en agriconnector 7-10 mm because the 7-10mm agriconnector should not be punched into a line.

Manual punch for open field connectors (7 / 8 mm)
A 7 and 8mm manual punch is available for the start connector.

71850-105891	DAN-manual punch 7 mm barb (8)
45000-001400	Manual punch aluminium 8 mm (9)
45000-002010	Grip/inserter start connector (10)
45000-002020	Punch inserter for start connector

- Application: Agriconnector, Super starter and Stick starter



